


Model No.4331D CORDLESS JIG SAW



Model No.4331D CORDLESS JIG SAW

Item	Parts No.	Description	I/C	Qty	New/Old	Opt. 1	Opt. 2	Note
001	416644-0	SWITCH BUTTON		1				
002	233194-8	COMPRESSION SPRING 4		1				
003	183267-6	HOUSING SET		1				
D10		INC. 51,69,70						
004	265995-6	TAPPING SCREW 4X18		6	*			
004-1	265A48-7	TAPPING SCREW 4X18	O	6				
005	266050-7	TAPPING SCREW 4X30		1				
006	911148-2	PAN HEAD SCREW M4X25		1				
007	651976-0	SWITCH TG73BD		1				
008	416642-4	SWITCH LEVER		1				
009	643918-8	BATTERY HOLDER		1				
010	164749-7	HOLDER		1				
011	152645-1	GEAR HOUSING COVER COMPLETE		1	*			
011-1	153391-9	GEAR HOUSING COVER COMPLETE	<	1				
C10	253310-6	THIN WASHER 10		1				
C20	421821-1	DUST SEAL 8		1				
012	265995-6	TAPPING SCREW 4X18		4	*			
012-1	265A48-7	TAPPING SCREW 4X18	O	4				
013	256693-3	PIN 4		1				
014	231314-8	COMPRESSION SPRING 4		2				
015	316608-3	HOLDER		1				
016	961017-7	STOP RING E-3		1				
017	310028-3	SLIDER		1				
018	265035-0	COUNTERSUNK HEAD SCREW M4X10		2				
019	344232-2	THRUST PLATE		1				
020	151426-0	RETAINER COMPLETE		1	*			
C10	256667-4	PIN 4		1	*			
C20	322709-7	ROLLER		1	*			
C30	961017-7	STOP RING E-3		1	*			
020-1	152947-5	RETAINER COMPLETE	X	1				
C10	268074-9	PIN 4		1				
C20	152950-6	ROLLER COMPLETE		1				
C30	961017-7	STOP RING E-3		1				
021	852646-6	NAME PLATE 4331D		1				
022	165089-6	ROD		1				
023	265894-2	H.S.SET SCREW(CUP POINT) M6X8		1				
024	344137-6	SLIDE PLATE		1				
025	421692-6	GASKET		1				
026	961004-6	RETAINING RING S-8		1				
027	212010-7	NEEDLE BEARING 607		1				

Please order the parts with part number.

Print Date 17/6/2019

Model No.4331D CORDLESS JIG SAW

Item	Parts No.	Description	I/C	Qty	New/Old	Opt. 1	Opt. 2	Note
028	922126-7	HEX. SOCKET HEAD BOLT M4X16		2				
029	152454-8	CRANK COMPLETE		1				
030	253792-2	FLAT WASHER 26		1				
031	253715-0	FLAT WASHER 6		1				
032	344792-4	BALANCE PLATE		1				
033	256289-0	PIN 6		1				
034	344792-4	BALANCE PLATE		1				
035	253715-0	FLAT WASHER 6		1				
036	253715-0	FLAT WASHER 6		1				
037	256143-8	PIN 6		1				
038	344134-2	PUSH PLATE		1				
039	253792-2	FLAT WASHER 26		1				
040	212043-2	NEEDLE BEARING 810		1				
041	253811-4	FLAT WASHER 5		1				
042	256235-3	PIN 5		1				
043	226428-6	HELICAL GEAR 51		1				
044	212043-2	NEEDLE BEARING 810		1				
045	253139-0	FLAT WASHER 8		1				
046	256288-2	PIN 8		1				
047	266134-1	TAPPING SCREW ST 4X8		3				
048	344791-6	MOTOR BRACKET		1				
049	265035-0	COUNTERSUNK HEAD SCREW M4X10		1				
050	629735-0	DC MOTOR 12V		1				
C10	226385-8	HELICAL GEAR 8		1				
D10		INC. 67,68						
051	183267-6	HOUSING SET		1				
D10		INC. 3,69,70						
052	272231-3	LEVER 17		1				
053	231314-8	COMPRESSION SPRING 4		1				
054	216008-6	STEEL BALL 4		1				
055	961018-5	STOP RING E-5		1				
056	316883-1	BASE		1				
057	331435-7	CLAMP PLATE		1				
058	344443-9	BASE PLATE		1				
059	922126-7	HEX. SOCKET HEAD BOLT M4X16		1				
060	266055-7	HEX. SOCKET HEAD BOLT M5X8		4				
061	322893-8	SAFETY WIRE		1				
062	253715-0	FLAT WASHER 6		1				
063	344784-3	SEAL PLATE		1				
064	443106-5	FELT 10-20		1				

Please order the parts with part number.

Print Date 17/6/2019

Model No.4331D CORDLESS JIG SAW

Item	Parts No.	Description	I/C	Qty	New/Old	Opt. 1	Opt. 2	Note
065	911006-2	PAN HEAD SCREW M3X8		1				
066	631372-8	CONTROLLER		1				
067	191971-3	CARBON BRUSH CB-430		1				
068	643929-3	BRUSH HOLDER CAP		2				
069	931102-0	HEX. NUT M4		1				
070	819080-3	MAKITA LABEL		1				
A01	344532-0	SET PLATE		1	*			
A02	414938-7	BATTERY COVER		1				
A03	415524-7	ANTI-SPLINTERING DEVICE		1				
A04	783201-2	HEX. WRENCH 3		1				
A05	792522-1	JIG SAW BLADE B-22		1	*			
A05-1	A-85737	JIGSAW BLADE NO.B22	<	1				
A06	792538-6	JIG SAW BLADE B-10		1	*			
A06-1	A-85628	JIGSAW BLADE NO.B10	<	1				
A07	A-02294	JIG SAW BLADE BR-13		1	*			
A07-1	A-85793	JIGSAW BLADE NO.BR13	<	1				
A08	824553-3	PLASTIC CARRYING CASE		1				
C10	416661-0	LATCH		2				
A09A	192597-4	BATTERY 1222 SET		1				
A09C_B	193100-4	NI-MH(2.6A) BATTERY 1234 SET		1				
A09C_C	193100-4	NI-MH(2.6A) BATTERY 1234 SET		1				
E01A	414938-7	BATTERY COVER		1				
E01C	414938-7	BATTERY COVER		1				
E03A	192597-4	BATTERY 1222 SET		1				
E05C	193100-4	NI-MH(2.6A) BATTERY 1234 SET		1				

Please order the parts with part number.

Print Date 17/6/2019